



TEMAFLOOR 6

Application process

Concrete needs to be repaired and readied for preparation

Concrete must be of sufficient strength to accept system

Preparation as a minimum

- Surface grinding, blast tracking & vacuuming

Coating Process

- 1) **Temafloor 400** - blinded with addition of brown sand 0,4-0.8 mm to aid adhesion of next layer



- 2) **Temafloor PU 0229 grey** (Applied @ 0,51/m² to give about 2mm DFT) + anti-slip white sand @ 0,6-1,2 mm broadcasted on to wet film to fill the surface thoroughly until the surface was covered with loose, unbonded aggregate at a spread rate of approximately 6kg/m²



TIKKURILA INDUSTRIAL UK
VALTTI BUILDING
27 MARNIN WAY
WEST EDINBURGH BUSINESS PARK
EDINBURGH EH12 9GD

TEL: +44 (0)131 334 4999
FAX: +44 (0)131 334 3987
EMAIL: enquiries@valtti.co.uk
www.valtti.co.uk



3) **Final Layer - Temafloor PU-UV or PU-UV Color** (applied @ about 1l/m² to give about 1mm DFT)



TIKKURILA INDUSTRIAL UK
VALTTI BUILDING
27 MARNIN WAY
WEST EDINBURGH BUSINESS PARK
EDINBURGH EH12 9GD

TEL: +44 (0)131 334 4999
FAX: +44 (0)131 334 3987
EMAIL: enquiries@valtti.co.uk
www.valtti.co.uk